

TURN N LEARN ACTIVITY CENTER COVER


The usefulness of the Fisher-Price Turn N Learn Activity Center can be extended by adding this textured cover. The cover is made of four machine washable fabrics: plush, satin, terrycloth, and seersucker. It fits snugly onto the Turn N Learn and is particularly interesting to babies who are visually impaired.

Materials needed:


- A Fisher-Price Turn N Learn Activity Center
- Four pieces of machine washable cloth of differing textures such as velvet, satin, terrycloth and seersucker
- Two large jingle bells (3/4" diameter)
- Sewing thread

Tools needed:


- Scissors
- Pins
- Sewing machine



TURN N LEARN TOY WITH COVER



TURN N LEARN COVER PATTERN



FOLDING OF EDGE DETAIL